

Neresheim, Abteikirche  
Holzhey, 1797, rest. 1979



**I Hauptwerk C–f<sup>3</sup>**

1.	Bordon ( <i>ab g<sup>0</sup></i> )	32'
2.	Principal	16'
3.	Octav	8'
4.	Coppel	8'
5.	Violoncell	8'
6.	Piffarre	8'
7.	Quintadena	8'
8.	Octav	4'
9.	Flöt	4'
10.	Quinte	2 2/3'
11.	Octav	2'
12.	Mixtur VII	
13.	Cimbal V	
14.	Cornet V ( <i>ab g<sup>0</sup></i> )	
15.	Trompet	8'
16.	Cromorne	8'
17.	Claron	4'

**II Oberwerk C–f<sup>3</sup>**

18.	Principal	8'
19.	Bordon	8'
20.	Flaut travers <sup>[Anm. 1]</sup>	8'
21.	Salicet	8'
22.	Gamba	8'
23.	Unda Maris <sup>[Anm. 2]</sup>	8'
24.	Hofflöt	4'
25.	Waldflöt	4'
26.	Feldflöt	4'
27.	Flagiolet	2'
28.	Nazard V	
29.	Sexquialter III	
30.	Sonnet II	
31.	Hoboe	8'
32.	Douce Clarinet	8'

**III Echowerk C–f<sup>3</sup>**

33.	Nachthorn	8'
34.	Dulciana <sup>[Anm. 3]</sup>	8'
35.	Spitzflöt	4'
36.	Fugari <sup>[Anm. 4]</sup>	4'
37.	Syflöt	2'
38.	Cornet IV	
39.	Hörnle III	
40.	Vox Humana <sup>[Anm. 4]</sup>	8'

*Tremulant*

- *Koppeln:* II/I, III/I, III/II,  
I/P, II/P

**Pedal C–f<sup>1[Anm. 5]</sup>**

41.	Prestant	16'
42.	Bordon	16'
43.	Flauten	8'
44.	Flötenbass	8'
45.	Violonbass	8'
46.	Bompart	16'
47.	Trompet	8'
48.	Claron	4'
	Pauken	A und d <sup>0</sup>